


Corrections Facility Mirrors

Stainless Steel Full Dome Mirror

Assembly Guide:



NOTE: Retaining Ring with Counter-Sunk Holes is optional for Stainless Steel Domes. (ie: Frameless Domes with Counter-Step Holes can be mounted directly to ceiling with appropriate tamperproof fixings).

NOTE: If installing with Rawl Spikes, it is recommended to use a punch. This is to eliminate damage to the mirror face or powder-coated frame.

Cleaning Instructions

Clean with soap and water and then with a soft, lint free, damp cloth.

DO NOT USE:

- abrasives
- acids

POLISH:

Using a commercial Stainless Steel Polish is NOT recommended as the protective layer will leave a residue on the highly polished mirror faces. Rubbing plain white flour on a dry stainless steel mirror face with a dry cloth will polish the mirror to its original brilliance.

GRAFFITI REMOVAL:

Any graffiti should be removed from the mirror face as soon as possible and preferably within 24 hours with a suitable lacquer thinners. Not all graffiti cleaning agents are suitable. Failure to use an approved cleaning agent may damage the mirror surface.

OPTIONAL POWDER COATED FRAMES:

Do not use harsh cleaning products or products that will leave a residue, as this will damage the powder coating which protects the frame.

AC-SFD-71



See Over For Suggested
Fastening Methods



Distributed in Australia By:
Acрил Convex Mirrors
41 Quinn Drive, Keilor Park, VIC 3040
Free Phone: 1800-802-506:
Email: sales@acrilconvex.com.au

Made in New Zealand By:
Bennett Mirror Technologies Ltd
Email: mirrors@bennettmirror.com
www.duravision.net

Corrections Facility Mirrors

Suggested Fastening Methods

RAWL SPIKES




Installation: Drill a hole into the base material to a depth of at least 60mm. The tolerances of the drill bit used should meet the requirements of ISO/DIN Standard 8035. Blow the hole clean of dust and other material. Drive the Spike through the appropriate mirror face hole (and frame when used) ensuring the head is sitting firmly against the mirror or frame and recessed as shown in the above diagram.

NOTE: Care should be taken not to overdrive the Spike so as to cause damage to the powder coated surface of the frame. Finish off by applying (optional) a bead of non-pick sealant around the mirror or frame and the wall to prevent the secretion of small objects (eg razor blades etc).

DuraVision Rawl Spike Punch:

The DuraVision designed punch for inserting spikes can significantly reduce the risk of damaging the mirror face and optional frame during installation.

TORX SECURITY SCREWS



Installation: It is recommended to use a 3/16" (4.76mm) Straight Shank Tanged Bit to drill the hole. The hole must be at least 2" or 50mm overall depth and free of any debris. By using the #27, 1/4" (6.35mm) Hex Bit the special Hi-Lo thread literally taps into masonry materials. The high, sharp thread with its notched cutting edge cuts deeply and easily. The alternating low thread provides stability for fast, accurate driving. Torx Tamperproof masonry screws are the optimal fastening solution for use in concrete, brick, or hollow block.