


# DuraVision™ Correctional Facility Mirrors

## Maximum Stainless Steel Anti Ligature Vanity Mirror



Remove retaining bolts supplied for transportation use only.

It is recommended that a "non pick sealant" be applied after installation where the mirror frame makes contact with the walls to reduce ligature risk.

## Stainless Steel Cleaning Instructions

Clean with soap and water and then with a soft, lint free, damp cloth.

### DO NOT USE:

- abrasives
- acids

### POLISH:

Using a commercial Stainless Steel Polish is NOT recommended as the protective layer will leave a residue on the highly polished mirror faces. Rubbing plain white flour on a dry stainless steel mirror face with a dry cloth will polish the mirror to its original brilliance.

### GRAFFITI REMOVAL:

Any graffiti should be removed from the mirror face as soon as possible and preferably within 24 hours with suitable lacquer thinners. Not all graffiti cleaning agents are suitable. Failure to use an approved cleaning agent may damage the mirror surface.

AC-SVW-85



See Over For Suggested  
Fastening Methods




Distributed in Australia By:  
Acрил Convex Mirrors  
41 Quinn Drive, Keilor Park, VIC 3040  
Free Phone: 1800-802-506:  
Email: sales@acrilconvex.com.au

Made in New Zealand By:  
Bennett Mirror Technologies Ltd  
Email: mirrors@bennettmirror.com  
www.duravision.net

# DuraVision™ Corrections Facility Mirrors


## Suggested Fastening Methods

### RAWL SPIKES



- ← Powder coated steel frame
- ← Stainless steel mirror face
- ← Concrete wall
- ← Rawl Spike

**Mushroom Head Type 316 Stainless Steel SPIKE.**  
**Anchor Size: 6.5x50mm**  
**Drill Dia. 6.5mm**




**Installation:** Drill a hole into the base material to a depth of at least 60mm. The tolerances of the drill bit used should meet the requirements of ISO/DIN Standard 8035. Blow the hole clean of dust and other material. Drive the Spike through the appropriate mirror face hole (and frame when used) ensuring the head is sitting firmly against the mirror or frame and recessed as shown in the above diagram.

NOTE: Care should be taken not to overdrive the Spike so as to cause damage to the powder coated surface of the frame. Finish off by applying (optional) a bead of non-pick sealant around the frame and the wall to prevent the secretion of small objects (eg razor blades etc).

DuraVision Rawl Spike Punch:

The DuraVision designed punch for inserting spikes can significantly reduce the risk of damaging the mirror face and frame during installation.

### TORX SECURITY SCREWS



- ← Powder coated steel frame
- ← Stainless steel mirror face
- ← Concrete wall
- ← Torx Screw

**Button Head Torx Security Masonry Screw**  
**Size: 1/4" x 1 3/4" (6.35mm x 44.45mm)**  
**Driver Size: #27 Torx Security 1/4" (6.35mm) Hex Bit**  
**Drill Dia: 3/16" (4.76mm)**



**Installation:** It is recommended to use a 3/16" (4.76mm) Straight Shank Tanged Bit to drill the hole. The hole must be at least 2" or 50mm overall depth and free of any debris. By using the #27, 1/4" (6.35mm) Hex Bit the special Hi-Lo thread literally taps into masonry materials. The high, sharp thread with its notched cutting edge cuts deeply and easily. The alternating low thread provides stability for fast, accurate driving. Torx Tamperproof masonry screws are the optimal fastening solution for use in concrete, brick, or hollow block.